

mimio®

MimioProjector
User Guide



© 2013 Mimio. All rights reserved. Revised 7/18/2013.

No part of this document or the software may be reproduced or transmitted in any form or by any means or translated into another language without the prior written consent of Mimio.

Mimio, MimioClassroom, MimioProjector, and MimioStudio are registered marks in the United States and other countries. All other trademarks are the property of their respective holders.

Contents

| | |
|--|----|
| MimioProjector | 7 |
| What's Included | 7 |
| About MimioProjector | 8 |
| About the Control Panel | 10 |
| About the Remote Control | 11 |
| About the Connection Ports | 13 |
| Getting Started | 15 |
| Connecting the Projector | 15 |
| Connecting to a Computer | 16 |
| Connecting to a Video Source | 17 |
| Setting Up the Remote Control | 18 |
| Turning On the Power | 19 |
| Turning Off the Power | 20 |
| Status Lights | 21 |
| Adjusting the Projected Image | 22 |
| Resizing the Projected Image | 22 |
| Focusing the Projected Image | 22 |
| Changing the Projector Settings | 23 |
| Navigating the Projector Menu | 23 |
| Adjusting the 3D Settings | 26 |
| 3D | 26 |
| 3D Invert | 26 |
| 3D Format | 26 |
| 1080p @24 | 26 |
| Adjusting the Interactive Settings | 27 |
| Adjusting the Options | 27 |
| Logo | 27 |
| Logo Capture | 28 |
| Auto Source | 28 |
| Input | 28 |
| Auto Power Off | 28 |
| Lamp Setting | 28 |
| Lamp Hours Used (Normal) | 28 |
| Lamp Hours Used (ECO) | 28 |

| | |
|--------------------------------------|----|
| Lamp Life Reminder | 28 |
| Lamp Power Mode | 29 |
| Clear Lamp Hours | 29 |
| Dynamic Black | 29 |
| High Altitude | 29 |
| Filters Remind | 29 |
| Information | 30 |
| Adjusting the Picture | 30 |
| Color Mode | 30 |
| Wall Color | 30 |
| Brightness | 30 |
| Contrast | 30 |
| Sharpness | 30 |
| Saturation | 31 |
| Hue | 31 |
| Gamma | 31 |
| Color Temperature | 31 |
| Color Space | 31 |
| Adjusting the Screen | 31 |
| Aspect Ratio | 31 |
| Phase | 32 |
| Clock | 32 |
| Horizontal Position | 32 |
| Vertical Position | 32 |
| Digital Zoom | 32 |
| Vertical Keystone | 32 |
| Ceiling Mount | 32 |
| Adjusting the General Settings | 33 |
| Language | 33 |
| Menu Location | 33 |
| Closed Caption | 33 |
| VGA OUT (Standby) | 33 |
| Auto Screen (12V Out) | 33 |
| Test Pattern | 34 |
| Security | 34 |
| Setting the Password | 34 |
| Reset | 34 |
| Adjusting the Volume | 35 |
| Mute | 35 |

| | |
|--|----|
| Volume | 35 |
| Microphone Volume | 35 |
| Caring for MimioProjector | 37 |
| Replacing the Remote Control Battery | 37 |
| Replacing the Lamp | 38 |
| Cleaning the Dust Filters | 39 |
| Getting Help | 41 |
| General Troubleshooting | 41 |
| Projector stops responding to all controls | 41 |
| Lamp burns out or makes a popping sound | 41 |
| Image Troubleshooting | 41 |
| No image is displayed | 41 |
| A partial, scrolling, or incorrect image is displayed | 42 |
| The notebook computer display is not displaying an image | 42 |
| Image is unstable or flickering | 42 |
| Image has vertical flickering bar | 42 |
| Image is out of focus | 42 |
| Image is stretched when displaying 16:9 DVD image | 43 |
| Image is too small or too large | 43 |
| Image is displayed with slanted sides | 43 |
| Image is reversed | 43 |
| 3D Troubleshooting | 43 |
| A blurry double image is displayed | 43 |
| Two images are displayed side-by-side | 43 |
| Image not displayed in 3D | 43 |
| Sound Troubleshooting | 43 |
| Remote Control Troubleshooting | 44 |
| Contacting Mimio | 44 |
| Compatibility Modes | 45 |
| VGA Analog | 45 |
| PC Signal | 45 |
| Extended Wide Timing | 46 |
| Component Signal | 47 |
| HDMI Digital | 48 |
| PC Signal | 48 |
| Extended Wide Timing | 49 |
| Video Signal | 50 |


| | |
|---|-----------|
| HDMI 1.4a Mandatory 3D Timing - Video Signal | 50 |
| Technical and Environmental Information | 51 |
| Usage Notice | 51 |
| Warnings | 51 |
| Precautions | 51 |
| Regulation & Safety Notices | 52 |
| FCC Notice | 52 |
| Notice | 52 |
| Caution | 52 |
| Operating Conditions | 53 |
| Notice: Canadian Users | 53 |
| Remarque à L'intention des Utilisateurs Canadiens | 53 |
| Declaration of Conformity for EU countries | 53 |
| Projector Mount Safety Notices | 53 |
| Environmental Information | 54 |
| Documentation Feedback | 55 |

Chapter 1

MimioProjector

What's Included

The MimioProjector package contains the following items:




| | | | |
|---|------------------------|---|-------------------------|
| 1 | Remote control | 4 | Power cord |
| 2 | Remote control battery | 5 | Projector with lens cap |
| 3 | VGA cable | | |

If you are missing any of the items above, contact Customer Support.


About MimioProjector

The following figure shows the major components of the MimioProjector.


Front View



Back View




Bottom View



| | | | |
|---|---------------|---|-------------------------------|
| 1 | Focus ring | 6 | Input/Output connection ports |
| 2 | Lens | 7 | Power connector |
| 3 | Control panel | 8 | Elevator feet |
| 4 | Lamp cover | 9 | Elevator feet spacers |
| 5 | IR Receiver | | |

About the Control Panel


The following figure shows the components of the MimioProjector control panel.




| | | |
|---|--------------------------|--|
| 1 | Navigation keys | Navigate through menus and make selections. |
| 2 | Power button | Turn the projector on and off. |
| 3 | Power status light | Indicates the power status of the projector. |
| 4 | Lamp status light | Indicates the projector lamp status. |
| 5 | Temperature status light | Indicates the projector temperature status. |
| 6 | Source button | Select an input signal. |
| 7 | Resync button | Automatically synchronize the PC analog timing to the optimized condition. |
| 8 | Menu/Exit button | Open the menu screen or exit a menu. |
| 9 | IR receiver | |

About the Remote Control


The following figure shows the components of the MimioProjector remote control.



| | | |
|----|--|--|
| 1 | Source | Select an input signal. |
| 2 | Resync | Automatically synchronize the PC analog timing to the optimized condition. |
| 3 | HDMI | Switch to HDMI input. |
| 4 | Video | Switch to Composite Video or S-Video input. |
| 5 | 3D | Turn on and off the 3D menu. |
| 6 | Menu | Open the menu screen or exit a menu. |
| 7 | Freeze | Freeze or unfreeze the image on the screen. |
| 8 | Blank | Hide or show the screen image. |
| 9 | Power | Turn the projector on or off. |
| 10 | PC | Switch to VGA-A/VGA-B input. |
| 11 | Keystone  | Adjust image until the sides are vertical. |
| 12 | Aspect ratio | Select the desired aspect ratio. |
| 13 | Navigation keys | Navigate through menus and make selections. |
| 14 | Volume up | Increase the audio volume. |
| 15 | Volume down | Decrease the audio volume. |
| 16 | Mute | Mute the audio. |

About the Connection Ports

The following figure shows the connection ports available on the MimioProjector .



| | | | |
|---|--|----|--------------------------------|
| 1 | Mini-USB | 9 | Audio output |
| 2 | HDMI | 10 | 12V trigger relay (12V, 250mA) |
| 3 | VGA output | 11 | RS232 |
| 4 | VGA in 1 | 12 | VGA in 2 |
| 5 | Audio in 1 (for VGA in 1) | 13 | Audio in 2 (for VGA in 2) |
| 6 | S-Video | 14 | Composite video input |
| 7 | Left/Right RCA audio input (for composite video input) | 15 | 3.5 mm microphone input |
| 8 | Left/Right RCA audio input (for S-Video) | 16 | Power |

This page intentionally left blank for double-sided printing.

Chapter 2

Getting Started

Review the following topics to install and start using your MimioProjector.


- Connecting the Projector
- Setting Up the Remote Control
- Turning On the Power

Connecting the Projector

You can connect MimioProjector to a computer or other video source..

Connecting to a Computer

The following figure shows the connection methods available for connecting the MimioProjector to a computer.




| | | | |
|---|-----------------------|---|-------------|
| 1 | Power cord (included) | 5 | RS232 cable |
| 2 | Audio cable | 6 | HDMI cable |
| 3 | VGA to DVI-A cable | 7 | USB cable |
| 4 | VGA cable (included) | 8 | 12V DC jack |

Setting Up the Remote Control


Before using the remote control for the first time, remove the transparent insulation tape.

To set up the remote control


1. Press firmly and slide the battery holder out of the battery compartment.




2. Remove the battery from the battery holder.
3. Remove the transparent insulation tape.



4. Replace the battery holder with the + polarity marking facing up as shown.



5. Slide the battery holder back into the battery compartment and press firmly.




Turning On the Power

The projector has an auto-off feature which automatically turns the projector off when no input signal is received by the projector for a set amount of time.



For information about setting the amount of time the projector will stay on before automatically turning off, see **Auto Power Off** on page 28.

To turn the projector on

1. Securely connect the power cord and signal cable.
When connected, the Power status light turns red.
2. Press  on the control panel or on the remote control.
The Power status light turns blue.
3. Turn on the source that you want to display on the screen (computer, notebook, video player, and so on).
The projector detects the source automatically and displays the source image.
4. If multiple sources are connected to the projector, press **Source** on the control panel or on the remote control to switch between inputs.

Turning Off the Power

To turn the projector off

1. Press  on the control panel or on the remote control.
A confirmation message is displayed on the projector screen.
2. Press  again to turn the projector off.
The Power status light turns red and blinks rapidly. The projector fans continue to run for approximately one minute to ensure that the projector cools properly.
When the system is finished cooling, the fans turn off and the Power status light turns solid red, indicating that the projector is in standby mode.
3. Unplug the power cord.

Status Lights

| Message | Lamp status light Red | Temperature status light Red | Power status light Red | Power status light Blue |
|---|--------------------------|---|---|----------------------------|
| Power plug | Flash ON to OFF 100ms | Flash ON to OFF 100ms | Flash ON to OFF 100ms | -- |
| Standby | -- | -- | ON | -- |
| Power button ON | -- | -- | -- | ON |
| Cooling state | -- | -- | 0.5 second H (ON) 0.5 second L (OFF) flashing | -- |
| Power button OFF Cooling completed; Standby mode | -- | -- | ON | -- |
| Firmware download | ON | ON | ON | -- |
| Thermal sensor error The following message is displayed: 1. Make sure air inlets and outlets are not blocked. 2. Make sure the environment temperature is under 40 degrees C | -- | ON | -- | ON |
| Fan lock error The following message is displayed: The projector will switch off automatically. | -- | 0.5 second H (ON) 0.5 second L (OFF) flashing | -- | ON |
| Lamp error (lamp, lamp driver, color wheel) | ON | -- | -- | ON |

Adjusting the Projected Image

You can adjust the size and focus of the projected image.

Resizing the Projected Image

The size of the projected image depends on the distance of the projector from the screen. The following table describes the general guidelines for projector distance from the screen.


| Screen Size (16:10) | | Projection Distance (A) | | Projection Distance (B) | |
|---------------------|------|-------------------------|-----|-------------------------|-----|
| Diagonal (inch) | mm | Inch | mm | Inch | mm |
| 70 | 1778 | 20.4 | 517 | 7.2 | 182 |
| 80 | 2032 | 23.5 | 596 | 10.3 | 262 |
| 87.2 | 2215 | 25.8 | 655 | 12.6 | 320 |
| 90 | 2286 | 26.7 | 677 | 13.5 | 343 |
| 100 | 2540 | 29.9 | 759 | 16.7 | 424 |

Projection Distance A(mm) = Screen size (mm) x 0.296. Tolerance is around 3.1%.

For example, Projection Distance (655 mm) = Screen Size (2215 mm) x 0.296.

Focusing the Projected Image


Use the focus ring to adjust the focus of the projected image. Turn the ring until the image is clear.



Changing the Projector Settings

You can adjust the projector image and change the projector settings using the projector menus. The projector automatically detects the input source.


To change the projector settings

1. Press **Menu** on the control panel or on the remote control to display the projector main menu.
2. Use the navigation keys to select the desired menu item.
3. If the menu item has an arrow icon, , press **▶** to display the submenu for that setting, and then use the navigation keys to select the desired menu item.
4. Press **◀** or **▶** to adjust the selected setting.
5. Press **Menu** to return to the previous menu or to exit the menu screen.

Navigating the Projector Menu

The following table describes the structure of the projector menu and submenus.

| Main Menu | Submenu | Settings |
|-----------|-------------|---|
| PICTURE | Color Mode | Brightest / PC / Movie / Game / User |
| | Wall Color | White / Light Yellow / Light Blue / Pink / Dark Green |
| | Brightness | 0~100 |
| | Contrast | 0~100 |
| | Sharpness | 0~31 |
| | Saturation | 0~100 |
| | Hue | 0~100 |
| | Gamma | 0~3 |
| | Color Temp. | Low / Mid / High |
| | Color Space | AUTO / RGB / YUV |

| Main Menu | Submenu | Settings | |
|-----------|----------------------|--|----------|
| SCREEN | Aspect Ratio | AUTO / 4:3 / 16:9 / 16:10 | |
| | Phase | 0~31 | |
| | Clock | -50~50 | |
| | H. Position | -10~10 | |
| | V. Position | -10~10 | |
| | Digital Zoom | 1~10 | |
| | V Keystone | -20~20 | |
| | Ceiling Mount | Front / Front Ceiling / Rear / Rear Ceiling | |
| SETTING | Language | English / Deutsch / Français / Italiano / Español / Português / Polski / Русский / Svenska / Norsk / 簡體中文 / 日本語 / 한국어 / Türkçe / 繁體中文 / Nederlands / العربية | |
| | Menu Location |  | |
| | Closed Caption | Off / CC1 / CC2 / CC3 / CC4 | |
| | VGA Out (Standby) | Off / On | |
| | Auto Screen(12V out) | Off / On | |
| | Test Pattern | Off / On | |
| | Security | Security | Off / On |
| | | Change Password | 000000 |
| | Reset | No / Yes | |
| AUDIO | Mute | Off / On | |
| | Volume | 0~32 | |
| | Microphone Volume | 0~32 | |

| Main Menu | Submenu | | Settings |
|-----------|----------------------|--------------------------|---|
| OPTIONS | Logo | | Default / User |
| | Logo Capture | | |
| | Auto source | | Off / On |
| | Input | | HDMI / VGA-A / VGA-B / S-Video / COMPOSITE |
| | Auto Power Off | | (min) 0~120 |
| | Lamp Setting | Lamp Hours Used (Normal) | |
| | | Lamp Hours Used (ECO) | |
| | | Lamp Life Reminder | Off / On |
| | | Lamp Power Mode | ECO / Normal / Extreme Dimming |
| | | Clear Lamp Hours | No / Yes |
| | Dynamic Black | | Off / On |
| | High Altitude | | Off / On |
| | Dust Filter Reminder | Filters Remind (Hour) | |
| | | Cleaning Up Reminder | No / Yes |
| | Information | | Model Name / SNID / Source / Resolution / Software Version / Color Space / Aspect Ratio |

| Main Menu | Submenu | Settings |
|-------------|----------------------|--|
| 3D | 3D | AUTO / Off / On |
| | 3D Invert | Off / On |
| | 3D Format | Frame Packing / Side-by-Side (Half) / Top and Bottom / Frame Sequential / Field Sequential |
| | 1080p @ 24 | 96Hz / 144Hz |
| INTERACTIVE | Interactive Settings | Off / IR Camera |

Adjusting the 3D Settings

You can adjust the 3D settings for your projector.

3D

You can choose how the projector handles 3D images.

- **Auto** - select the 3D image automatically whenever an HDMI 1.4a 3D timing identification signal is detected
- **Off** - turn off 3D functionality
- **On** - turn on 3D functionality

3D Invert

If you see a discrete or overlapping image while using DLP 3D glasses, you may need to turn on this feature to get the best picture. This feature adjusts the left/right image sequence.

3D Format

When using 3D mode, select the 3D format that matches the format used by the input source.

- **Frame Packing** - supports HDMI 1.4a 3D input signals
- **Side-by-Side (Half)** - supports HDMI 1.4a 3D input signals
- **Top and Bottom** - supports HDMI 1.4a 3D input signals
- **Frame Sequential** - supports DLP Link 3D input signals from VGA / HDMI connector and HQFS 3D input signals from Composite/S-video connector
- **Field Sequential** - supports HQFS 3D input signals from Composite/S-video connector

1080p @24

Use this feature to select 96 or 144 Hz refresh rate as using 3D glasses in the 1080p @ 24 frame packing.

Adjusting the Interactive Settings

Use this setting to turn on and off the Interactive Pen function.

- **IR Camera** - the Interactive Pen function is on
- **Off** - the Interactive Pen function is off

Before turning on Interactive, unplug the mini-USB cable that connects your computer to the projector. After turning on Interactive, plug the mini-USB cable back in.


 **Notes**

- This feature is only available when displaying images from HDMI/VGA input.
- This feature is not available when using 3D or Dynamic Black.

An external IR camera is required to use the Interactive feature. The IR camera must be connected to the projector before the projector is mounted.

To connect the IR camera

1. Remove the camera connector cover from the projector.



2. Plug the camera into the camera connector.

Adjusting the Options

From the Options menu, you can change many of the projector settings as well as view the projector information.

Logo

You can select the image to display on projector startup.

- **Default**- displays the default screen on projector startup
- **User** - displays an image of your choice on projector startup
See **Logo Capture** on page 28 for information on selecting an image.

Logo Capture

You can capture an image to display on projector startup.

- ▶ Press ▶ to capture the image currently displayed on the screen.



Notes

- Ensure that the displayed image does not exceed the native resolution of the projector (WXGA:1280x800).
- Logo Capture is not available when 3D is enabled.
- The aspect ratio should be set to Auto before using capturing an image.

Auto Source

Select how to handle searching for an input source when the projector loses signal from the current input source.

- **On** - the projector searches for signals from other input sources when the current input signal is lost
- **Off** - the projector searches only for a signal from the current input connection when the current input signal is lost

Input

Use this option to select the input types that the projector will search for.

1. From the **Options** menu, select **Input**, and then press ▶.
2. Select the input that you do not want the projector to search for, and then press ▶ to clear the check box for the selected input type.

Auto Power Off

The projector has an auto-off feature which automatically turns the projector off when no input signal is received by the projector for a set amount of time.

You can set the amount of time the projector will stay on before automatically turning off .

Lamp Setting

Lamp Hours Used (Normal)

View the amount of time the projector has been used in normal lamp power mode.

Lamp Hours Used (ECO)

View the amount of time the projector has been used in ECO lamp power mode.

Lamp Life Reminder

You can choose whether or not the projector displays a warning message when the lamp is nearing end of life.

Lamp Power Mode

The following lamp power modes are available:

- **Normal** - the projector lamp is at full brightness
- **ECO** - the projector lamp is dimmed to reduce power consumption, extending the life of the lamp
- **Extreme Dimming** - the projector lamp is dimmed 30 percent to reduce power consumption, extending the life of the lamp

Clear Lamp Hours

Reset the lamp hours counter after replacing the projector lamp.

Dynamic Black

Use Dynamic Black to display the image with the optimum contrast by automatically providing signal compensation to suit the currently displayed image.



Notes

- This feature is only available when the color mode is set to Movie.
- This feature is not available when using 3D or Interactive.
- Lamp Power Mode cannot be used with this feature.

High Altitude

The fan power required varies depending on the altitude you are at. Set this option appropriately to ensure that the projector cools properly.

- **On** - the built-in fans automatically run at a variable speed according to the internal temperature of the projector
- **Off** - the built-in fans run at high speed
Select this option when using the projector at altitudes above 5000 feet/1524 meters.

Filters Remind

You can set a time to be reminded to perform filter maintenance.

- **Filters Remind (Hour)** - Set the number of hours that pass before you are reminded to clean the dust filters. The dust filters should be cleaned after every 500 hours of use. Clean the filters more frequently if the projector is used in a dusty environment.
- **Cleaning Up Reminder** - Once you have cleaned or replaced the dust filters, reset the timer to be reminded then next time the filters require maintenance.

Information

Display the following projector information:

- Model name
- Software version
- SNID
- Color space
- Source
- Aspect ratio
- Resolution

Adjusting the Picture

Many settings are available for adjusting the picture displayed by the projector..

Color Mode

The following optimized color modes are available for viewing various types of images.

- **Brightest** - for brightness optimization
- **PC** - for viewing meeting presentations
- **Movie** - for viewing video content
- **Game** - for viewing game content
- **User** - for storing your manually configured settings

Wall Color

Select the wall color that the image is projected onto. The projector settings automatically adjust to show the correct image tone, compensating for color deviation due to wall color.

Brightness

Adjust the brightness of the image.

- ▶ Press ◀ to darken image.
- ▶ Press ▶ to lighten the image.


Contrast

The Contrast controls the difference between the lightest and darkest parts of the picture. Adjusting the contrast changes the amount of black and white in the image.

- ▶ Press ◀ to decrease the contrast.
- ▶ Press ▶ to increase the contrast.


Sharpness

Adjust the sharpness of the image.

-  This setting is only supported when Movie is selected as the color mode.
- ▶ Press ◀ to decrease the sharpness.
- ▶ Press ▶ to increase the sharpness.


Saturation

Adjust the color saturation of the image. The saturation ranges from black and white to fully saturated color.

-  This setting is only supported when Movie is selected as the color mode.
 - ▶ Press ◀ to decrease the amount of saturation in the image.
 - ▶ Press ▶ to increase the amount of saturation in the image.

Hue

Adjust the red and green color balance.

-  This setting is only supported when Movie is selected as the color mode.
 - ▶ Press ◀ to increase the amount of green in the image.
 - ▶ Press ▶ to increase the amount of red in the image.

Gamma

Adjusts the representation of dark scenery. The greater the gamma value, the bright dark scenery will appear.

- ▶ Press ◀ to decrease the gamma value.
- ▶ Press ▶ to increase the gamma value.

Color Temperature

At a higher color temperature, the image appears colder; at a lower color temperature, the image appears warmer.

Color Space

Select the appropriate color matrix type; Auto, RGB, or YUV.

Adjusting the Screen

You can adjust the screen and display settings for the projector.

Aspect Ratio

The following aspect ratios are available for scaling the projected image.

- **Auto** - keeps the image the original width-to-height ratio and maximizes the image to fit native horizontal or vertical pixels
- **4:3** - scales the image to fit the screen and displays using a 4:3 ratio
- **16:9** - scales the image to fit the width of the screen and adjusts the height to display the image using a 16:9 ratio
- **16:10** - scales the image to fit the width of the screen and adjusts the height to display the image using a 16:10 ratio

Phase

Change the signal timing of the display to match the timing of the graphics card for your computer. If the image appears unstable or flickers, use this setting to correct it.

- ▶ Press ◀ to decrease the signal timing.
- ▶ Press ▶ to increase the signal timing.


Clock

Change the display data frequency to match the frequency of the graphics card for your computer. Adjust this setting only if the image appears to flicker vertically.

- ▶ Press ◀ to decrease the data frequency.
- ▶ Press ▶ to increase the data frequency.


Horizontal Position

Adjust the horizontal position of the projected image.

-  The range for this setting depends on the input source.
- ▶ Press ◀ to move the image left.
- ▶ Press ▶ to move the image right.

Vertical Position

Adjust the vertical position of the projected image.

-  The range for this setting depends on the input source.
- ▶ Press ◀ to move the image down.
- ▶ Press ▶ to move the image up.

Digital Zoom

Use this setting to zoom the projected image.

- ▶ Press ◀ to reduce the size of the image.
- ▶ Press ▶ to magnify the image on the projection screen.

Vertical Keystone

Use this setting to adjust the vertical distortion of the image. If the image appears trapezoidal, adjust this setting to make the image appear rectangular.

- ▶ Press ◀ or ▶ to adjust the vertical distortion of the image.

Ceiling Mount

Select the location of the ceiling mounted projector.

- **Front** - the image is projected straight onto the screen.
- **Front Ceiling** - the image turns upside down (default).
- **Rear** - the image appears reversed.
- **Rear Ceiling** - the image appears reversed and upside down.

Adjusting the General Settings






You can adjust many of the general settings for your projector.

Language

Select the language to use when displaying the projector menus.

Menu Location

Select the location for the projector menu to display.

- | | |
|---|--------------|
|  | Top left |
|  | Top right |
|  | Center |
|  | Bottom left |
|  | Bottom right |

Closed Caption

The following closed caption options are available:

- Off
- CC1
- CC2
- CC3
- CC4.

VGA OUT (Standby)

You can enable VGA OUT connection to display the projector image on an additional display.

- ▶ Select **On** to enable VGA OUT connection.

Auto Screen (12V Out)

If you are using the projector with a powered screen, you can choose to automatically lower and raise the screen when the projector is powered on and off.

- **On** - the screen lowers automatically when you turn the projector power on and raises automatically when you turn the projector power off
- **Off** - the screen does not lower and raise automatically when you turn the projector power on and off

Test Pattern

You can display a test pattern to test the image settings.

- **On** - show the test pattern
- **Off** - hide the test pattern

Security


You can choose to require a password to be entered each time the projector is turned on. The following security settings are available:

- **On** - the user must enter a password in order to power on the projector
- **Off** - the user is not required to enter a password in order to power on the projector


Setting the Password

If the password is entered incorrectly 3 times, the projector automatically shuts down. If you forget your password, contact Mimio Customer Support for assistance.

To set the password for the first time

1. From the **Security** menu, select **Change Password**, and then press ►.
2. Use the navigation keys to enter 000000 as the current password, and then press ►.
 If the password is entered incorrectly 3 times, the projector automatically shuts down.
3. Use the navigation keys to enter a new password, and then select **ENTER** to confirm. The password must be six digits.
4. Use the navigation keys to enter the new password again, and then select **ENTER** to confirm.

To change the password

1. From the **Security** menu, select **Change Password**, and then press ►.
2. Use the navigation keys to enter the current password, and then press ►.
 If the password is entered incorrectly 3 times, the projector automatically shuts down.
3. Use the navigation keys to enter a new password, and then select **ENTER** to confirm. The password must be six digits.
4. Use the navigation keys to enter the new password again, and then select **ENTER** to confirm.

Reset

Resetting the projector resets all projector settings to the factory defaults.


- Select **Yes** to reset the projector.

Adjusting the Volume

You can adjust the projector volume settings.

Mute


You can choose to mute the projector audio.

 You can also press **Mute** on the remote control to turn mute on and off.

Volume

Use this setting to increase or decrease the speaker volume.

- ▶ Press ◀ to decrease the volume.
- ▶ Press ▶ to increase the volume.

 You can also use the volume buttons on the remote control to adjust the volume.

Microphone Volume

Use this setting to increase or decrease the microphone volume.

- ▶ Press ◀ to decrease the volume.
- ▶ Press ▶ to increase the volume.

This page intentionally left blank for double-sided printing.

Caring for MimioProjector


Replacing the Remote Control Battery

To ensure safe operation, please observe the following precautions :


- Use only CR2025 type battery.
Using the incorrect battery type may cause explosion.
- Avoid contact with water or liquid.
- Do not expose the remote control to moisture or heat.
- Do not drop the remote control.
- If the battery leaks while inserted in the remote control, carefully wipe the case clean and install new battery.
- Dispose of used battery according to battery instructions.

To replace the battery


1. Press firmly and slide the battery holder out of the battery compartment.



2. Remove the old battery from the battery holder.
3. Insert a new battery into the battery holder with the + polarity marking facing up as shown.



4. Slide the battery holder back into the battery compartment and press firmly.



Replacing the Lamp

The projector automatically detects the lamp life. When the lamp is nearing the end of life, a warning is displayed on the screen.


When the warning appears, contact Mimio Customer Support to order a replacement lamp as soon as possible. Make sure the projector is off and has cooled down for at least 60 minutes before changing the lamp.

Notes

- MimioProjector uses an OSRAM P-VIP 240/0.8 E20.8 bulb.
- The screws on the lamp cover and the lamp cannot be removed.
- The projector cannot be turned on while the lamp cover is removed.
- Do not touch the glass area of the lamp. Oils from your skin can cause the lamp to shatter. Use a dry cloth to clean the lamp module if the lamp is accidentally touched.

To remove the lamp module

1. Press the power button to turn off the projector.
2. Allow the projector to cool down for at least 60 minutes.
3. Unplug the power cord.
4. Using a screwdriver, loosen the two screws on the lamp cover.
5. Lift and remove the lamp cover.
6. Using a screwdriver, loosen the two screws on the lamp module.
7. Pull the lamp handle up and slowly and carefully remove the lamp module.



To insert the new lamp module

1. Slowly and carefully insert the lamp module into the lamp compartment and push the lamp handle down.
2. Using a screwdriver, tighten the two screws on the lamp module.
3. Replace the lamp cover.
4. Using a screwdriver, tighten the two screws on the lamp cover.

5. Plug the power cord into a wall outlet.
6. Press the power button to turn on the projector.
7. Clear the lamp hours. See **Clear Lamp Hours** on page 29 for information about clearing the lamp hours.

Cleaning the Dust Filters

The dust filters should be cleaned after every 500 hours of use. Clean the filters more frequently if the projector is used in a dusty environment.

When the dust filters need to be cleaned, a warning is displayed on the screen.


When the warning appears, clean the dust filters as soon as possible. Make sure the projector is off before cleaning the dust filters.

Notes

- The dust filters should be used in dusty environments.
- Properly maintaining the dust filters prevents overheating of the projector and related damage.

To clean the dust filters

1. Press the power button to turn off the projector.
2. Unplug the power cord.
3. Pull the latch and slowly and carefully remove the dust filters from the projector.



4. Use a vacuum to clean the dust filters.
5. Slide the dust filters back into the projector.
6. Plug the power cord into a wall outlet.
7. Press the power button to turn on the projector.
8. Reset the filter maintenance reminder.
See **Filters Remind** on page 29 for information about resetting the filters reminder.

This page intentionally left blank for double-sided printing.

Chapter 5

Getting Help

Review this chapter if you encounter a problem with your projector.

If you are unable to solve a problem, this chapter also describes how to contact Mimio Technical Support.

- General Troubleshooting
- Image Troubleshooting
- 3D Troubleshooting
- Sound Troubleshooting
- Remote Control Troubleshooting
- Contacting Mimio

General Troubleshooting

Review this section if you encounter a general problem with your projector.

Projector stops responding to all controls

1. Press the power button to turn the projector off.
2. Unplug the power cord.
3. After 20 seconds, or longer, plug the power cord back in.
4. Press the power button to turn the projector on.

Lamp burns out or makes a popping sound

When the lamp reaches end of life, it burns out and may make a loud popping sound. The projector will not turn on again until the lamp module is replaced. For information about replacing the lamp, see **Replacing the Lamp** on page 38.

Image Troubleshooting

Review this section if you encounter a problem with the projector image.


No image is displayed

- Ensure all cables and power connections are correctly and securely connected as described in **Connecting the Projector** on page 15.
- Ensure the pins of connectors are straight and not broken.
- Ensure that the projection lamp is securely installed.
- Ensure that the Blank feature is turned off.

A partial, scrolling, or incorrect image is displayed

- Press **ReSync** on the remote control.

If you are using a computer as the input source, do the following:

1. Verify that the display resolution setting for your computer is set at 1080p or lower. Refer to the documentation for your computer for information about changing the display resolution for your computer.
 -  If you experience difficulty changing resolutions or your monitor freezes, restart all equipment including the projector.
2. If you are using a notebook computer, press the keyboard buttons needed to toggle the output setting.

| Notebook Brand | Function Keys |
|----------------|---|
| Acer | [Fn]+[F5] |
| Asus | [Fn]+[F8] |
| Dell | [Fn]+[F8] |
| Gateway | [Fn]+[F4] |
| IBM/Lenovo | [Fn]+[F7] |
| HP/Compaq | [Fn]+[F4] |
| NEC | [Fn]+[F3] |
| Toshiba | [Fn]+[F5] |
| Mac Apple | System Preference -> Display -> Arrangement -> Mirror display |

The notebook computer display is not displaying an image

Some notebook computers may deactivate the screens when a second display device is in use. Each has a different way to be reactivated. Refer to the documentation for your computer for detailed information.

Image is unstable or flickering

- Adjust the Phase setting on the projector. See **Phase** on page 32 for information about changing the Phase setting.
- Change the monitor color setting on your computer.

Image has vertical flickering bar

- Adjust the Clock setting on the projector. to make an adjustment. See **Clock** on page 32 for information about changing the Clock setting.
- Check and reconfigure the display mode of your graphic card to make it compatible with the projector.

Image is out of focus

- Adjust the focus ring on the projector lens.
- Make sure the projection screen is within the required distance.

Image is stretched when displaying 16:9 DVD image


- When you play anamorphic DVD or 16:9 DVD, the best image is displayed when the projector is set to use 16: 9 format.
- If displaying a 4:3 format DVD title, set the projector to use 4:3 format.
-  If the image is still stretched, verify that the format setting on your DVD player is set correctly.

Image is too small or too large

- Move the projector closer to or further from the screen.
- Adjust the aspect ratio setting on the projector. See **Aspect Ratio** on page 31 for information about adjusting the aspect ratio.

Image is displayed with slanted sides

- If possible, reposition the projector so that the image is centered on the screen.
- Adjust the vertical keystone setting on the projector. See **Vertical Keystone** on page 32 for information about adjusting this setting.

Image is reversed

Verify that the ceiling mount setting on the projector is set correctly. See **Ceiling Mount** on page 32 for information about adjusting this setting.

3D Troubleshooting

Review this section if you encounter a problem with 3D mode.

A blurry double image is displayed

Make sure the 3D feature is off. For information about turning off 3D, see **3D** on page 26.

Two images are displayed side-by-side

Set the 3D format to Side-by-Side (Half). For information about changing the 3D format, see **3D Format** on page 26.

Image not displayed in 3D

- Make sure your 3D glasses are powered on.
- Make sure the batteries in the 3D glasses have sufficient charge.
- Set the 3D format to Side-by-Side (Half).
For information about changing the 3D format, see **3D Format** on page 26.

Sound Troubleshooting

Review this section if you encounter a problem with the projector sound.

- If you are playing sound from an external source, make sure you have the audio cable securely connected to the source device and the audio input on the projector.

- Make sure no external speakers are connected.
- Make sure the volume is not set to the minimum.
- Make sure the Mute feature is off.

Remote Control Troubleshooting

Review this section if you encounter a problem with the projector remote control.

- Make sure the operating angle of the remote control is within $\pm 30^\circ$ both horizontally and vertically of one of the IR receivers on the projector.
- Make sure there are no obstructions between the remote control and the projector.
- Move to within 7 m ($\pm 0^\circ$) of the projector.
- Make sure the battery is inserted correctly.
- Replace the battery.

Contacting Mimio

Mimio maintains an Internet Web site that offers support for MimioClassroom products. In addition, Mimio's Technical Support department is available by phone.

Web site: www.mimio.com

Phone: (877) 846-3721

Visit the Support section of our Web site at www.mimio.com to contact us by email.

Compatibility Modes

VGA Analog

PC Signal

| Modes | Resolution | V. Frequency [Hz] | H. Frequency [Hz] |
|---------------|------------|-------------------|-------------------|
| VGA | 640x480 | 60 | 31.5 |
| | 640x480 | 67 | 35.0 |
| | 640x480 | 72 | 37.9 |
| | 640x480 | 75 | 37.5 |
| | 640x480 | 85 | 43.3 |
| | 640x480 | 120 | 61.9 |
| IBM | 720x400 | 70 | 31.5 |
| SVGA | 800x600 | 56 | 35.1 |
| | 800x600 | 60 | 37.9 |
| | 800x600 | 72 | 48.1 |
| | 800x600 | 75 | 46.9 |
| | 800x600 | 85 | 53.7 |
| | 800x600 | 120 | 77.4 |
| Apple, MAC II | 832x624 | 75 | 49.1 |
| XGA | 1024x768 | 60 | 48.4 |
| | 1024x768 | 70 | 56.5 |
| | 1024x768 | 75 | 60.0 |
| | 1024x768 | 85 | 68.7 |
| | 1024x768 | 120 | 99.0 |

| Modes | Resolution | V. Frequency [Hz] | H. Frequency [Hz] |
|---------------|-------------------|--------------------------|--------------------------|
| Apple, MAC II | 1152x870 | 75 | 68.7 |
| SXGA | 1280x1024 | 60 | 64.0 |
| | 1280x1024 | 72 | 77.0 |
| | 1280x1024 | 75 | 80.0 |
| QuadVGA | 1280x960 | 60 | 60.0 |
| | 1280x960 | 75 | 75.2 |
| SXGA+ | 1400x1050 | 60 | 65.3 |
| UXGA | 1600x1200 | 60 | 75.0 |

Extended Wide Timing

| Modes | Resolution | V. Frequency [Hz] | H. Frequency [Hz] |
|--------------|-------------------|--------------------------|--------------------------|
| WXGA | 1280x720 | 60 | 44.8 |
| | 1280x800 | 60 | 49.6 |
| | 1366x768 | 60 | 47.7 |
| | 1440x900 | 60 | 59.9 |
| WSXGA+ | 1680x1050 | 60 | 65.3 |

Component Signal

| Modes | Resolution | V. Frequency [Hz] | H. Frequency [Hz] |
|--------------|-------------------|--------------------------|--------------------------|
| 480i | 720x480(1440x480) | 59.94(29.97) | 15.7 |
| 576i | 720x576(1440x576) | 50(25) | 15.6 |
| 480p | 720x480 | 59.94 | 31.5 |
| 576p | 720x576 | 50 | 31.3 |
| 720p | 1280x720 | 60 | 45.0 |
| | 1280x720 | 50 | 37.5 |
| 1080i | 1920x1080 | 60(30) | 33.8 |
| | 1920x1080 | 50(25) | 28.1 |
| 1080p | 1920x1080 | 23.98/24 | 27.0 |
| | 1920x1080 | 60 | 67.5 |
| | 1920x1080 | 50 | 56.3 |

HDMI Digital

PC Signal

| Modes | Resolution | V. Frequency [Hz] | H. Frequency [Hz] |
|---------------|-------------------|--------------------------|--------------------------|
| VGA | 640x480 | 60 | 31.5 |
| | 640x480 | 67 | 35.0 |
| | 640x480 | 72 | 37.9 |
| | 640x480 | 75 | 37.5 |
| | 640x480 | 85 | 43.3 |
| | 640x480 | 120 | 61.9 |
| IBM | 720x400 | 70 | 31.5 |
| SVGA | 800x600 | 56 | 35.1 |
| | 800x600 | 60 | 37.9 |
| | 800x600 | 72 | 48.1 |
| | 800x600 | 75 | 46.9 |
| | 800x600 | 85 | 53.7 |
| | 800x600 | 120 | 77.4 |
| Apple, MAC II | 832x624 | 75 | 49.1 |
| XGA | 1024x768 | 60 | 48.4 |
| | 1024x768 | 70 | 56.5 |
| | 1024x768 | 75 | 60.0 |
| | 1024x768 | 85 | 68.7 |
| | 1024x768 | 120 | 99.0 |

| Modes | Resolution | V. Frequency [Hz] | H. Frequency [Hz] |
|---------------|-------------------|--------------------------|--------------------------|
| Apple, MAC II | 1152x870 | 75 | 68.7 |
| SXGA | 1280x1024 | 60 | 64.0 |
| | 1280x1024 | 72 | 77.0 |
| | 1280x1024 | 75 | 80.0 |
| QuadVGA | 1280x960 | 60 | 60.0 |
| | 1280x960 | 75 | 75.2 |
| SXGA+ | 1400x1050 | 60 | 65.3 |
| UXGA | 1600x1200 | 60 | 75.0 |

Extended Wide Timing

| Modes | Resolution | V. Frequency [Hz] | H. Frequency [Hz] |
|--------------|-------------------|--------------------------|--------------------------|
| WXGA | 1280x720 | 60 | 44.8 |
| | 1280x800 | 60 | 49.6 |
| | 1366x768 | 60 | 47.7 |
| | 1440x900 | 60 | 59.9 |
| WSXGA+ | 1680x1050 | 60 | 65.3 |

Video Signal

| Modes | Resolution | V. Frequency [Hz] | H. Frequency [Hz] |
|-------|-------------------|-------------------|-------------------|
| 480p | 640x480 | 59.94/60 | 31.5 |
| 480i | 720x480(1440x480) | 59.94(29.97) | 15.7 |
| 576i | 720x576(1440x576) | 50(25) | 15.6 |
| 480p | 720x480 | 59.94 | 31.5 |
| 576p | 720x576 | 50 | 31.3 |
| 720p | 1280x720 | 60 | 45.0 |
| | 1280x720 | 50 | 37.5 |
| 1080i | 1920x1080 | 60(30) | 33.8 |
| | 1920x1080 | 50(25) | 28.1 |
| 1080p | 1920x1080 | 23.98/24 | 27.0 |
| | 1920x1080 | 60 | 67.5 |
| | 1920x1080 | 50 | 56.3 |

HDMI 1.4a Mandatory 3D Timing - Video Signal

| Modes | Resolution | V. Frequency [Hz] | H. Frequency [Hz] |
|--------------------|------------|-------------------|-------------------|
| Frame Packing | 720p | 50 | 31.5 |
| | 720p | 59.94/60 | 15.7 |
| | 1080p | 23.98/24 | 15.6 |
| Side-by-Side(Half) | 1080i | 50 | 31.5 |
| | 1080i | 59.94/60 | 31.3 |
| Top and Bottom | 720p | 50 | 45.0 |
| | 720p | 59.94/60 | 37.5 |
| | 1080p | 23.98/24 | 33.8 |

Technical and Environmental Information

This chapter contains technical information for the MimioProjector.

For product specifications and compliance information, visit the Documentation section of the Support area of our Web site at www.mimio.com.

Usage Notice

Follow all warnings, precautions, and maintenance as recommended in this user guide.

Warnings

- Do not look into the projector lens when the lamp is on. The bright light may hurt and damage your eyes.
- To avoid the risk of fire or electric shock, do not expose the projector to rain or moisture.
- Do not open or disassemble the projector as this may cause electric shock.
- When replacing the lamp, allow the unit to cool down first. Follow the instructions as described under **Replacing the Lamp** on page 38.
- The projector automatically detects the life of the lamp. Be sure to replace the lamp when the projector displays the lamp warning message.
- After replacing the projector lamp, reset the lamp hours setting. See **Clear Lamp Hours** on page 29 for information about resetting the lamp hours.
- When turning the projector power off, ensure that the cooling cycle completes before disconnecting the power. Allow 10 seconds for the projector to cool down.
- Do not block the light path between the light source and the lens with any object. Doing so could cause the object to catch on fire.
- Do not look into or point the laser pointer on your remote control into any person's eyes. Laser pointers can cause permanent damage to eyesight.

Precautions

- Turn off and unplug the power plug from the AC outlet before cleaning the product.
- Use a soft dry cloth with mild detergent to clean the display housing.
- Disconnect the power plug from the AC outlet if the product is not being used for a long period of time.

Do not do the following

- Clean the lens.
- Block the ventilation slots and openings on the unit.
- Use abrasive cleaners, waxes, or solvents to clean the unit.
- Use under the following conditions:
 - In extremely hot, cold, or humid environments.
 - Ensure that the ambient room temperature is between 5°C - 40°C.
 - Ensure relative humidity is a maximum of 80%, non-condensing.
 - In areas susceptible to excessive dust and dirt.
 - Near any appliance generating a strong magnetic field.
 - In direct sunlight.

Regulation & Safety Notices

This section lists the general notices of your projector.

FCC Notice

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Notice

Shielded cables All connections to other computing devices must be made using shielded cables to maintain compliance with FCC regulations.

Caution

Changes or modifications not expressly approved by the manufacturer could void the user's authority, which is granted by the Federal Communications Commission, to operate this projector.

Operating Conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference and
2. This device must accept any interference received, including interference that may cause undesired operation.

Notice: Canadian Users

This Class B digital apparatus complies with Canadian ICES-003.

Remarque à L'intention des Utilisateurs Canadiens

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

Declaration of Conformity for EU countries

- EMC Directive 2004/108/EC (including amendments)
- Low Voltage Directive 2006/95/EC
- R & TTE Directive 1999/5/EC (if product has RF function)

Projector Mount Safety Notices

Read these warnings carefully and use the product as intended.

- The manufacturer shall not be legally responsible for any equipment damage or personal injury caused by incorrect installation or operation.
- The wall mount is designed for easy installation and removal. The manufacturer shall not be liable for damage to equipment or personal injuries arising from human factors or acts of God, such as earthquake or typhoon.
- The wall mount must be installed by professional personnel only.
- To avoid any hazard caused by falling objects, a minimum of two persons are needed to install or remove the wall mount.
- Maintain ample space around the projector to ensure good ventilation.
- To ensure safety and avoid any accident, investigate the structure of the wall and select an appropriate and durable location for the product before installing.
- The wall must have load-carrying capability to sustain more than four times the total weight of the projector and the wall mount. Also make sure the wall has enough strength to withstand earthquakes and other shocks.
- Check the areas around the installation location carefully.
 - Do not install the product in an area subject to high temperature, humidity, or contact with water.
 - Do not install the product near air conditioner vents.
 - Do not install the product in a location subject to dust or fumes.
 - Do not install the product on slanted surfaces; install only on vertical walls.
 - Do not install the product in an area subject to vibrations or shocks.

- Do not install the product in an area subject to direct exposure to bright light; doing so may cause eye fatigue when viewing the display panel.
- Do not modify any accessory or use broken parts. Contact Mimio Customer Support with any questions.
- Tighten all screws, but do not apply excessive torque to any screw. Excessive torque may break or damage the screw or screw threads.
- The wall mount is rated for a maximum load of 15 Kg (33 lbs.).
- Do not hang or place any objects on the wall mount other than the projector.
- Drill holes and screws remain in the wall once the projector and wall mount are removed. Stains may occur after extended use.

Environmental Information

The equipment that you bought has required the extraction and use of natural resources for its production. It may contain hazardous substances for the health and the environment.

In order to avoid the dissemination of those substances in our environment and to diminish the pressure on the natural resources, we encourage you to use the appropriate take-back systems.

Those systems will reuse or recycle most of the materials of your end life equipment in a sound way.

The crossed-bin symbol marked on your device invites you to use those systems.



If you need more information on the collection, reuse and recycling systems, please contact your local or regional waste administration.

You can also contact Mimio for more information on the environmental performances of our products.

Documentation Feedback

We are constantly working to produce the highest quality documentation for our products. We welcome your feedback. Send us your comments or suggestions about our online Help, printed, or PDF manuals.

Please include the following information with your feedback:

- Product name and version number
- Type of document: printed manual, PDF, or online Help
- Topic title (for online Help) or page number (for printed or PDF manuals)
- Brief description of content (for example, step-by-step instructions that are inaccurate, information that requires clarification, areas where more detail is needed, and so on)
- Suggestions for how to correct or improve the documentation

We also welcome your suggestions for additional topics you would like to see covered in the documentation.

Send email feedback to:

`documentation@mimio.com`

Please keep in mind that this email address is only for documentation feedback. If you have a technical question, please contact Customer Service.

This page intentionally left blank for double-sided printing.