

MimioPad

The best way for teachers to manage the classroom is to become part of the classroom – to walk around and provide individual attention. Now teachers can break free from the front of the classroom while they control the interactive whiteboard from anywhere in the room. What's more, students can now collaborate – right from their desks. Teaching is easier when the students are engaged, so let them participate. It's a better way to learn.

"The MimioPad allows me the flexibility to move around my classroom. It's so much easier to assist my students and facilitate learning."

Tricia Fontenot Third-Grade Teacher Teachers rejoice! With the new MimioPad[™] wireless pen tablet, you can control your interactive whiteboard from anywhere in the classroom. And when you hand out up to nine tablets that can be simultaneously viewed and controlled on the interactive classroom display at the front of the room, it's collaborative learning from front row to last.

- Wireless convenience to control any Mimio interactive display from anywhere in the classroom.
- Frees teachers to move about, so they can help individual students and manage the classroom more effectively.

- New MimioStudio[™] Collaborate feature allows as many as nine tablets to be controlled by students and viewed on the primary classroom display at the same time.
- Can be used in combination with the existing iPads your school already has.
- Plug-and-play simplicity right out of the box.
- 16 shortcut keys to the common functions of MimioStudio classroom software.
- Convenient battery-free stylus.



Collaborative learning made easier.



Key Features

Package Contents

Wireless pen tablet, Lithium Ion battery, stylus with lanyard, USB cable, replacement pen cap, and shortcut reference card. MimioHub™ wireless receiver and MimioStudio classroom software available separately.

Specifications

Minimum Software Requirements

MimioStudio 10* and higher on a Windows, Mac, or Linux OS.

For specific system requirements, please visit mimio.com/support/downloads

Computer Interface – RF Wireless

RF wireless interface employs a 2.4 GHz bidirectional, pointto-point, wireless interface between the MimioPad and a USB-connected receiver on the computer.* Utilizes directsequence spread-spectrum transmission protocol. USB Cable—"micro-B" 5-pin male cable to female receptacle on MimioPad. Standard USB A connection to host PC to recharge battery and use without wireless receiver.

Data Transfer Rate-Wireless 16 Kbps

Tablet Battery

Lithium Ion battery Life (Fully Charged): 50 hours continuous; 5 days in typical use.

Tablet Weight

0.65 kg (1.43 lb) with battery.

Complete Packaged System Weight

1.15 kg (2.5 lb) with tablet, stylus, cable, and battery.

Tablet Dimensions

24.3 cm H x 27.9 cm W x 2.0 cm D (9.5 in. H x 11.0 in. W x 0.8 in. D)

Tablet Active Surface Area

20.3 cm W x 16.2 cm H (8 in. W x 6.4 in. H)

Resolution 2000 lpi

Stylus Pen

Electromagnetic pen (optionally tethered to tablet) has no battery. Move pen over tablet's active surface to hover the cursor over the desktop. Touch pen tip to tablet's active surface to emulate the leftclick of a computer mouse. For right-click, press the button on the pen while hovering above the pad surface.

Pen Reading Height 10 mm (0.39 in.)

Pen Report Rate

Pen Accuracy ±0.42 mm

Controls & Indicators On/Off button.

16 icon shortcut keys at top edge of tablet's active surface area activate MimioStudio Tools.

Two buttons activate Page Up/ Page Down functions.

LCD panel indicates battery charge status, stylus activity, device ID, and pad number.

Use with Interactive Displays

Can be used as a standalone interactive device or in tandem with an interactive whiteboard. If used with any of the Mimio interactive whiteboards, MimioPad tablets can be supported with a single activated installation of MimioStudio software.*

Multiple Devices

Up to 9 MimioPad tablets can be supported by a single MimioPad wireless receiver. Each device will be assigned a unique device number, displayed in the LCD panel on the tablet. A MimioPad tablet that has been connected to a MimioHub receiver with other MimioPad tablets may be removed and connected to a different MimioHub receiver and used independently of the original group.

Certification & Compliance FCC / CE / BSMI / SRRC / KCC / VCCI / C-Tick.

Product Warranty

Two-year warranty on MimioPad tablet from date of purchase, with an additional 3 years with product registration at mimio.com/warranty, for a total of 5 years.

* MimioStudio software and MimioHub wireless receiver sold separately

Contact your local Mimio representative.



© 2013 Mimio