mimio[®] Interactive + Capture & mimio[®] Studio – Specifications September 2009

| PLATFORM | WINDOWS (Studio v. 6.11) | MACINTOSH (Studio v. 6.22) | LINUX (Studio v. 6.2) | | |
|--|--|---|---|--|--|
| Package Contents | mimio Interactive (600-0045) | | | | |
| mimio Interactive + Ink | • mimio Xi Capture bar with linkU | ISB interface module | | | |
| Capture | mimio Mouse Interactive stylus p | oen + AA alkaline battery | | | |
| 6000050 (= 6000045 + 5800014) | • USB mini-B cable – 16′ / 4.87m | | | | |
| | ABS Plastic Snap-in mounting brackets (with 3M Command adhesive strips) 3 CD's containing installers for Windows 6.11 in 12 languages (English, French, Italian, German, Spanish, Russi | | | | |
| | | se-Traditional, Japanese, Korean, Arabic) a | · · · · · · · · · · · · · · · · · · · | | |
| | | ownloaded from the mimio.com website 9 | | | |
| | | Distributors in Brazil and Portugal. | | | |
| | Quick Start Install guide booklets for Interactive set up and use (Win,Mac & Linux – 12 languages) mimio Ink Capture kit (580-0014) Four (4) marker stylus pens with color smartCaps (red, green, blue, black) Four (4) extended smartCaps (orange, brown, yellow, purple) Marker stylus pen whiteboard holder | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | Eraser with holder (silver) | order | | | |
| | Four (4) Expo markers (red, green | n, blue, black) | | | |
| | Alkaline batteries for pens, & era | ser (N cell (LR1) x 4, AAA x 1) | | | |
| | Quick Start Install guide booklet | s for Ink Capture set up and use (Win,Mac | | | |
| Operating Systems Supported | Windows 98SE, ME, 2000, XP Home, | Macintosh OS X v. 10.4 or higher | Fedora 10+, openSUSE 11.1+, | | |
| Contain Demokratic | XP Pro, Vista | Daniel DC® C4 and batter | Ubuntu 8.04+ | | |
| System Requirements | Windows compatible PC with Pentium™ II 400 MHz+ processor or | PowerPC® G4 or better processors or Intel® processors, 700 MHz processor | Pentium II, 450 MHz processor or equivalent | | |
| | equivalent | 256MB RAM (512 recommended) | Ubuntu version 8.04. 8.10, 9.04 | | |
| | 32MB RAM minimum (256MB RAM | 200MB free disk space minimum | operating system software OR | | |
| | recommended) | CD ROM Drive or internet connection | Fedora version 10 and 11 operating | | |
| | 120MB free disk space minimum | to download software | system software OR | | |
| | CD ROM Drive | Available USB port | OpenSUSE version 11.1 operating | | |
| | Available USB port | Available Video Out port for | system software | | |
| | Available VGA port for interactive | interactive whiteboard use | 256 MB RAM minimum (512 MB RAM | | |
| | whiteboard use | | recommended) | | |
| | | | 200 MB free disk space | | |
| | | | CD-ROM drive or Internet | | |
| | | | connection to download software | | |
| | | | Available USB port (required to use | | |
| | | | a mimio device) | | |
| | | | Available Video Out port for interactive whiteboard use | | |
| Computer Interface | USB (USB 2.0 compliant) | <u> </u> | <u> </u> | | |
| - | | | | | |
| Data Transfer Rate - USB | USB Cable – "mini-B" 5 pin male cable to female receptacle on mimio device / standard USB A connection to host PC | | | | |
| | 64 kbps downloading lnk / 4.2 kbps under normal lnk capture or Interactive mouse use | | | | |
| Onboard Data Storage | ½ MB Flash memory stores 20 – 40 full boards of notes (depending on density of writing) | | | | |
| (stand-alone mode – requires Ink Capture Kit) | Automatically downloaded to computer when connected by USB cable with linkUSB interface module in mimio Xi capture bar. | | | | |
| <u> </u> | <u> </u> | | | | |
| Power options | -USB connection to the computer | | | | |
| (default/priority order) | -4 x AA batteries (40+ hours active use) -Optional AC adapter (US 110v or Int'l 100-240v) | | | | |
| Davier Communication | ' ' | <u>, </u> | | | |
| Power Consumption | Connected to computer via USB – 0.5 Watts Stand-alone with AC Adapter 110V - 0.75 Watts | | | | |
| | Stand-alone with AC Adapter 220V – 0.9 Watts | | | | |
| Capture Bar Weight | 1.1 lbs./0.5 kg with batteries, | | | | |
| Capture bar weight | 0.8 lbs./0.37 kg without batteries. | | | | |
| Complete System Weight | 2.6 lbs./1.2 kg with styli, eraser, cable | & hatteries | | | |
| Complete System Weight | .3 lbs. mimio Mouse | , & batteries | | | |
| Capture Bar Dimensions | | 1 in U • 46 cm x 7.0 cm W x 2.9 cm | | | |
| | Fully Open = 18.1 in. L x 2.8 in. W x 1.1 in. H • 46 cm L x 7.0 cm W x 2.8 cm H | | | | |
| • | Folded = 9.4 in. L x 2.8 in. W x 2.2 in. H • 24 cm L x 7.0 cm W x 5.7 cm H | | | | |
| William and A. C. A. C. | | | | | |
| Whiteboard Active Area (per device) | Interactive mode with projector supp | oorts 6.5-ft. x 8-ft. for lnk • 2 m x 2.4 m u | • | | |
| Whiteboard Active Area (per device) | Interactive mode with projector supp diagonal projection display and 113" | | • | | |
| Whiteboard Active Area (per device) | Interactive mode with projector supp diagonal projection display and 113" periphery of projection surface. | oorts 6.5-ft. x 8-ft. for lnk ullet 2 m x 2.4 m u diagonal in wide screen mode. Capture b | ar can be mounted anywhere on | | |
| • | Interactive mode with projector supp diagonal projection display and 113" of periphery of projection surface. Whiteboard mounting for Ink Capture | Forts 6.5-ft. \times 8-ft. for lnk • 2 m \times 2.4 m udiagonal in wide screen mode. Capture be: 4-ft. \times 8-ft. • 1.2 m \times 2.4 m (landscape or | ar can be mounted anywhere on portrait orientation). | | |
| Stylus Pen Signals | Interactive mode with projector supp diagonal projection display and 113" of periphery of projection surface. Whiteboard mounting for Ink Capture Ultrasound at 40 KHz (frequency) + | orts 6.5-ft. x 8-ft. for Ink • 2 m x 2.4 m u diagonal in wide screen mode. Capture b : 4-ft. x 8-ft. • 1.2 m x 2.4 m (landscape or Infrared at 880 nanometers/sec (waveleng | ar can be mounted anywhere on portrait orientation). | | |
| Whiteboard Active Area (per device) Stylus Pen Signals Resolution & Tracking Speed | Interactive mode with projector supp diagonal projection display and 113" of periphery of projection surface. Whiteboard mounting for Ink Capture Ultrasound at 40 KHz (frequency) + | Forts 6.5-ft. \times 8-ft. for lnk • 2 m \times 2.4 m udiagonal in wide screen mode. Capture be: 4-ft. \times 8-ft. • 1.2 m \times 2.4 m (landscape or | ar can be mounted anywhere on portrait orientation). | | |

| PLATFORM | WINDOWS (Studio v. 6.11) MACINTOSH (Studio v. 6.22) LINUX (Studio v. 6.2) | | | |
|---|--|--|--|--|
| Attachment Options | ABS Plastic mounting brackets w/ removable adhesive strips for permanent & repeatable position snap-in attachment. | | | |
| | 4 x suction cups for temporary attachment (up to 1 day on clean unscratched surface) Magnetic mounting brackets (optional accessory) | | | |
| Ink Capture Bar Positioning | mimio Xi Ink Capture bar can be mounted in location outside the projection area as long as the sensors face the | | | |
| nik capture bar i ositioning | projected surface which is within the maximum Active Area range of the device (see above). | | | |
| | For Ink Capture operation mimio Xi Ink Capture bar can be mounted in any corner of the white board either | | | |
| | vertically or horizontally. | | | |
| Controls & Indicators at the whiteboard | 5 Function Buttons on Xi Ink Capture bar: | | | |
| willeboard | -Ink Capture Recording Mode -Interactive Mode (selectable from options in Settings) | | | |
| | New Page mimio Tools palette (Toggle) - default Savon Markun (Toggle) - default | | | |
| | Duplicate Page Screen Markup (Toggle) - default Print Page Spotlight Presentation Effect (Toggle) - default | | | |
| | | | | |
| | Resize Notebook Window Reveal Screen Presentation Effect (Toggle) - default Calibrate / Re-calibrate Calibrate / Re-calibrate | | | |
| | • Calibrate / Re-calibrate • Calibrate / Re-calibrate Power On button LED (w/ low battery power indicator) / Memory reset button (recessed) | | | |
| | Ink Capture indicator LED / Data in memory indicator LED | | | |
| mimio Interactive Stylus | An ergonomically elegant stylus for Interactive use only. | | | |
| • | Two buttons on the stylus activate functions without touching the board. | | | |
| | Hover and Right Click are the default button assignments but users can preferences in mimio Studio Settings from a | | | |
| | menu that includes Left, Right, Middle, Back, and Forward mouse clicks or Hover / Mouse over. | | | |
| | Solid Teflon stylus tip insures ultra smooth action on all board or screen surfaces. | | | |
| | Uses single AA size Alkaline (50 hours) or rechargeable AA battery | | | |
| Marker Stylus Pens | mimio Stylus – uses Sanford Expo™ type dry erase markers (Basic and Extended colors supported) | | | |
| | Use 1 x N cell LR1 battery (24+ hours battery life actual writing time) | | | |
| Electronic Eraser | Dual surface - wide (3.9 in./10cm) and "finger tip" (0.75 in./1.9cm) erasure stroke for use in lnk Capture mode only | | | |
| | (interactive Eraser tool used for interactive erasure). | | | |
| | Uses 1 x AAA alkaline battery (12 hours battery life actual erasing time). | | | |
| Hardware Security | Supports Kensington style cable lock | | | |
| International Use | Batteries or Computer USB as primary power source means "Start up and Go" in any country. International AC | | | |
| | Adapter for AC powered use with Wireless or Stand-alone linkUSB capture mode. | | | |
| Product Warranty | 5 years on all hardware components. Limited lifetime on software. | | | |
| OPTIONAL ACCESSORIES | | | | |
| Package Contents | Wireless bi-directional interface module for Xi capture bar | | | |
| mimio Xi wireless upgrade | Matched USB transmitter/receiver | | | |
| 6100021 (North America) | AC Adapter (110 v only for North America / 100 – 240 v auto-switching for International w/ 4 plugs (EUR, | | | |
| 6100026 (International) | AUSTRALIA/NZ, US and UK)) | | | |
| | USB port extender cable | | | |
| Hardware configuration | Wireless interface module replaces removable linkUSB module in standard mimio Xi capture bar. Enables a dedicated 2.4GHz wireless connection to the computer through a USB "thumb drive" receiver with minimum range of | | | |
| | 30 ft./10m. | | | |
| | Does not require Bluetooth, special card, wireless networks or wireless PC. | | | |
| Wireless Connectivity | mimio Xi wireless interface employs a 2.4GHz bi-directional point-to-point wireless interface between the mimio Xi | | | |
| , | wireless module and a factory / serial number matched USB connected receiver on the computer. | | | |
| | Utilizes direct sequence spread spectrum transmission protocol. | | | |
| | Operates with mimio Studio for Win, Mac and Llnux, mimio v. 2.74 for Windows, and mimio 1.7 for Mac OSX. | | | |
| Data Transfer Rate Wireless | 16 kbps | | | |
| OTHER AVAILABLE ACCESSORIES | Carry Case, 16' Active USB extension cable, Magnetic Mounting Brackets, additional Mounting Brackets (single & 5 | | | |
| OTTER AVAILABLE ACCESSORIES | pack), Eraser felt pads Replacement Kit, Extended color smartCaps for Stylus pens, AC Adapter for Xi capture bar, | | | |
| | mimio Mouse interactive stylus | | | |
| SOFTWARE FEATURES | WINDOWS (Studio v. 6.11) MACINTOSH (Studio v. 6.21) LINUX (Studio v. 6.2) | | | |
| | | | | |
| Languages Supported | CD or downloadable installation for Windows in English, French, German, Dutch, Spanish, Japanese, Arabic, Italian Russian, Chinese Simplified, Chinese Traditional, Korean Hangul. | | | |
| | CD or downloadable installation for Mac in English , | | | |
| | Mac and Linux downloadable installers in English, French, German, Dutch, Spanish, Japanese, Arabic, Italian, | | | |
| | Russian, Chinese Simplified, Chinese Traditional, Korean Hangul. | | | |
| | Portuguese installers available from mimio Distributors in Portugal and Brazil | | | |
| Multiple mimio device support | Supports multiple mimio Xi devices (up to 4), permitting multiple simultaneous sessions or coverage of larger board | | | |
| Intonactive Whitehand | areas up to 8' x 16' (2.4m x 4.8m). or 4' x 32' (1.2m x 9.6m) | | | |
| Interactive Whiteboard | 9 point calibration (which can be stored and saved) permits any projected desktop on whiteboard to be controlled by the mimio stylus pen in Interactive Mode. User can switch between Interactive mode and Ink Capture mode from | | | |
| | the board. | | | |
| mimio Notebook | All pages created or captured in mimio Studio can be accessed and re-arranged in a convenient Notebook. | | | |
| mimio Notebook Page Views | All pages created or captured in mimio Studio can be accessed and re-arranged in Full Page or Thumbnail view in the | | | |
| | mi pages created or captured in millino studio can be accessed and re-arranged in ruil rage or inumbhall view in the | | | |

| PLATFORM | WINDOWS (Studio v. 6.11) | MACINTOSH (Studio v. 6.22) | LINUX (Studio v. 6.2) | | |
|---|--|---|---|--|--|
| | Studio Notebook. | | | | |
| | | | | | |
| Importing Data into Notebook | PowerPoint (ppt), Word (doc and docx), and Acrobat (pdf) files can be imported in their entirety into the Studio Notebook, where each document page becomes a background template page in Notebook which can be annotated, overlaid with other data objects and | PDF/Acrobat files can be imported in their entirety into the Studio Notebook at native resolution where each document page becomes a background template page in Notebook which can be annotated, overlaid with other data objects and presented. Any Mac application (MS | PowerPoint (ppt), Word (doc and docx), and Acrobat (pdf) files can be imported in their entirety into the Studio Notebook, where each document page becomes a background template page in Notebook which can be annotated, overlaid with other data objects | | |
| | presented. | Office, Keynote etc.) supporting Save As PDF or using the Print to PDF function can thus be imported into Notebook. | and presented. | | |
| mimio Tools | Thin vertical context sensitive floating tools palette for interactive use or editing/creation of Notebook pages directly from the computer. Includes Pens, Highlighters, Lines/Arrows, Rectangles, Ellipse, Polygons, Text Boxes, Image/Screen Capture / Import and an array of interactive controls and presentation tools. | | | | |
| Content Gallery | An application launched from the mimio Tools palette - includes an expandable directory tree containing more than 1,500 selectable background templates, image objects, multi-media objects and Lesson Plans in categories of Geography, Mathematics, Music, Planning, Reading & Language Arts, Science, Sports & Recreation as well as Miscellaneous Tools & Templates. Also includes a Directory of saved Screen Annotations. Users can create their own custom galleries, templates and image content from any digital image files, video, or Flash objects. Content/template Galleries can be easily exported/imported & shared between users. | | | | |
| Gallery Content Data Types Supported | Note: Adobe Flash is required to view multi-media content. - Mimio Studio Ink pages and files - All standard image file formats & screen clippings - All standard digital video formats (that play in Win media player) - Flash (swf) objects | | | | |
| Keyword and Search Functions for Content | Content in the Gallery can be accessed by keyword search. Users can add multiple keywords to any object through its Properties. | | | | |
| Object Locking and Transparency | Data objects of any kind (image, text, graphic, ink, video, Flash) can be locked in place anywhere on a Notebook page. Degree of transparency can be set from incrementally from 0% (solid) to 90% | | | | |
| Embedded Hyperlinks | Hyperlinks to other Studio pages, other documents, or web pages can be embedded in any data object on any Studio Notebook page | | | | |
| Object Manipulation Screen Clipping - Image, Screen Capture | All data objects (Ink, Graphics, Images, Text Boxes) can be moved, rotated, grouped/ungrouped, layered, and snapped to grid or angle on the Studio Notebook page. Grids can be displayed on page with snap to function. Any part of any screen, document, web page, dialog, or window can be selected and captured onto a Studio Notebook page from which it can be dragged/copied into a mimio Gallery as a background template or as a | | | | |
| Screen Markup and Annotation | foreground image object. mimio Tools can be used to annotate, markup or label any software application document page or screen in "Screen Annotation Mode". Annotated pages are automatically captured into a Screen Annotation directory in the Gallery from which pages can be selected and brought into other applications as image objects or into mimio Studio Notebook for further editing or presentation or printing | | | | |
| Presentation Tools | Integrated presentation tools include Reveal Screen, Spotlight, and direct web page access. | | | | |
| Internet Use | Direct access to default Home Page from mimio Tools. Any web page can be accessed, viewed, annotated and capture, or screen clipped interactively. | | | | |
| Handwriting Recognition | Converts handwritten mimio Ink data to editable ASCI text (English only) either live (online) as written into any text box or after the fact (offline) from any recorded ink notes (created in Ink Recording or Interactive modes) | | | | |
| mimio Recorder | Records any full screen, application wir with synchronized voice or other audio QuickTime MPEG-4 for Mac,), can be re QuickTime, or Real Player. | | N/A for Linux | | |
| Podcasting | .avi files created using mimio Studio Recorder can be converted to MPEG- 4 and imported into Apple iTunes (Win or Mac) for delivery via Podcast or synchronization with Apple video iPod devices. | MPEG-4 files created using mimio Studio Recorder (Mac) can be opened as QuickTime movie on a Mac, imported into iMovie, and imported into Apple iTunes (Win or Mac) for delivery via Podcast or synchronization with Apple video iPod devices. | N/A | | |
| mimio Ink Capture (requires Ink Capture kit) | mimio Studio software in Ink Capture mode captures notes, diagrams, charts, & illustrations drawn on the whiteboard in an object-based vector format (*.ink) that permits total editing (scale, color, line thickness, rotation) and reordering of pages and objects within pages. Ink data supports Copy & Paste of selected data to other applications. | | | | |
| Ink Capture – Store and Download (requires link USB interface module on Xi | | AA batteries, mimio Xi Capture bar can stall, without a computer connected. Not | | | |

| PLATFORM | WINDOWS (Studio v. 6.11) | MACINTOSH (Studio v. 6.22) | LINUX (Studio v. 6.2) | | |
|---|---|---|---------------------------------------|--|--|
| capture bar – NOT SUPPORTED WITH WIRELESS INTERFACE) | Studio when next connection to computer (Win or Mac) occurs. | | | | |
| Ink File Compatibility between mimio software Versions | mimio Ink data files recorded with previous versions of mimio software, whether on Windows or Mac can be opened in mimio Studio 6.02. mimio Studio 6.02 Ink data files cannot be opened in previous versions of mimio software. | | | | |
| Save As data "export" formats | Studio Notebook pages or complete Notebook can be Saved As HTML, BMP, JPG, GIF, PNG, TIF, EMF, WMF & PDF file formats | | | | |
| Wake on Write (WoW) (requires Ink Capture kit) | mimio Studio software can be initiated from the whiteboard in Ink Capture mode by touching a marker stylus pen to the board or into Interactive Mode by pressing the mimio Mouse interactive stylus to the board or the bottom button of the mimio Xi Capture bar. | | | | |
| Auto Save - Data Recovery | Unsaved mimio Notebook data is periodically saved in a temporary file from which it can be recovered in the event of system or application termination or crash. | | | | |
| Software Update | Default but selectable Settings option enables automatic updating of mimio Studio new versions | | | | |
| Internet conferencing (NetMeeting plug-in) | Ink Capture recorded in mimio Studio can be ported automatically to the virtual whiteboard of NetMeeting when any NetMeeting session is active. mimio Studio sessions and be viewed and shared via any Windows web or video conferencing solution that supports Application or Desktop Sharing | mimio Studio sessions and be viewed an compatible web or video conferencing s Desktop Sharing | · · · · · · · · · · · · · · · · · · · | | |
| Ink Data Magnification | Zoom buttons and rescaling tools permit magnification of high resolution anti-aliased Ink data up to 3000% | | | | |
| mimio Hardware support | mimio Studio supports mimio DMA-02 or later devices (mimio Xi, mimio Board, and some other devices). It does not support mimio "Classic" or mimio flipChart, Quartet, Turnstone Scribe or other DMA-01 or DMA-FC devices. Owners of earlier non supported devices should contact mimio about Trade-in options to upgrade their systems to use mimio Studio. | | | | |

09/09